

ICF BRACING RENTAL

Alignment bracing systems are available to rent from Amvic-Pacific.
Different types of bracing units are available.

Reechcraft Paneljack Pro system:

- ❑ An all metal (steel and aluminum) bracing, with an aluminum strongback, adjustable steel alignment kicker, scaffolding foot board platform, and safety backrail post.
- ❑ The renter provides foot boards, backrail 2x4, and all screws and other needed fasteners.
- ❑ The system serves several purposes:
 - It holds the wall perfectly straight and in line vertically
 - It provides rapid adjustment to maintain plumb
 - It secures the block while empty against being damaged by wind
 - It provides a safe platform for scaffolding foot boards to install the upper courses of block, and on which to work during the pour
 - It is installed quickly
- ❑ This is an OSHA compliant system.



Hybrid bracing system:



- ❑ This consists of an adjustable alignment turnbuckle foot that is attached to a 2x4 kicker and secured to the slab or ground. Galvanized steel “hat brackets” (3 or 4) are used to wrap a pair of 2x4's that have been nailed together to form a strongback, and to screw through and into the webs on each side of the stud..
- ❑ To make up a bracing unit, four 2x4x10' studs are required, and two are nailed together to form the strongback, and the other two used for the kicker, the footboard support, and the outrigger post.
- ❑ The renter builds the bracing units on site, and after completion, the wood parts can be used in the framing.
- ❑ Safe and sturdy if built properly, but not OSHA compliant.

RENTAL TERMS

- BASIS. Bracing rents at a daily rate starting from the time it is delivered or picked up, until returned to Amvic-Pacific by the renter, irrespective of whether it is placed in use and the time of actual usage.
- WE DELIVER – YOU RETURN. Amvic-Pacific will deliver the bracing to the renter's site, and the renter will install, tear down, clean, load, and return the bracing to Amvic-Pacific (or to another site that is no greater distance.)
- If desired or more expedient, the renter may pick up the bracing from Amvic-Pacific.
- The renter assumes all liability for safe and legal use of the bracing, and for repair or replacement in the event of damage or loss.
- Unless otherwise established, bracing rental is on a first-come first-served basis. While we are usually able to juggle to service all rental needs, Amvic-Pacific cannot guarantee the availability of bracing on a specific date.
- Bracing is also available for purchase. Contact us for details and pricing.

Amvic Pacific, Inc.
12531 Lowhills Rd – Nevada City CA 95959
530-265-9085